


Whether you have prepared a flat and level ground, poured footers, or a concrete slab. You must anchor your building somehow. If you have concrete you will want to use concrete anchors. If you have chosen to use unimproved ground it must be leveled and will require some type of anchor.



CONCRETE ANCHORS

Sometimes referred to as wedge anchors, contractors drill into the concrete and insert the anchor to fasten the building very securely to the concrete pad.



REBAR ANCHORS

Used in combination with every other anchor style except for concrete. Rebar anchors hold the baserail in place during construction to ensure a sturdy installation.



MOBILE HOME ANCHORS

Used to secure the building in ground installations only.

They are double helical in design.

Anchors shown are not to scale!



ASPHALT ANCHORS

Used in asphalt installations only. They have 4 fins that when driven into the ground hold the anchor in keeping the building secure during high wind conditions.